AFIT Transmission Position Error Troubleshooting

AFIT SUPPORT BULLETIN


Click on page link

[Transmission Position Error Message .... 2]

AFIT Transmission Position Error Message

INDEX PAGE

Error Message Appears: Vehicle transmission is not in Park or Neutral, or Clutch Pedal is not depressed.



The vehicle engine may not be safely cranked. Verify transmission lever position or manual transmission, depress clutch.

Note: *Vehicles equipped with ETRS (Electronic Transmission Range Select) uses BUS (GMLAN) data communications to determine lever position.*

AFIT is unable to retrieve this data to determine cranking safely.

Verify that the transmission or clutch pedal is in the proper position to safely crank the engine.

Select the **DOWN – OVERRIDE** to continue testing.